Sharkoon

REBEL9 PRO

Handbuch
Manual

Content

1. **Features**
2. **Package content**
3. **The case at a glance**
4. **Installation of a mainboard**
5. **Installation of a PSU**
6. **Installation of a HDD**
7. **Installation of an optical device**
8. **Installation of a 3.5" device**
9. **Installation of an add-on card**
10. **The pre-installed fans (Value and Window Edition only)**
11. **Installation of additional fans / optimized airflow**

Dear customer!

Congratulations for purchasing one premium quality SHARKOON product.
For a long life time and to take full advantage of this product we recommend that you read this manual completely.

Have a good time with our product!
SHARKOON Technologies

1. Features

- ATX case
- 9x 5.25" drive bays (6x external)
- Top I/O (Economy and Value): 2x USB2.0, 1x eSATA, 2x audio connectors, power and reset button
- Top I/O (Window): 1x USB3.0, 2x USB2.0, 2x audio connectors, power and reset button
- 7 slots for add-on cards
- Plastic front panel with air inlet, drive bay covers in mesh design
- Quick fasteners for optical drives, mainboard mounting with installation opening for coolers
- 2 openings for water cooling
- Cable management system
- Fan configuration:

	Economy Edition	**Value Edition**	**Window Edition**
Case front	1x 120mm fan (optional)	1x 120mm fan with LED as well as 3-pin and 4-pin connector (pre-installed)	1x 120mm fan with LED as well as 3-pin and 4-pin connector (pre-installed)
Side panel	2x 120mm fan (optional)	1x 250mm fan with LED, rpm controller and 4-pin connector (pre-installed)	Acrylic
Back side	1x 80mm or 1x 120mm fan (optional)	1x 120mm fan (pre-installed)	1x 120mm fan with LED as well as 3-pin and 4-pin connector (pre-installed)
Top panel	1x 120mm or 1x 140mm fan (optional)	1x 120mm or 1x 140mm fan (optional)	1x 120mm or 1x 140mm fan (optional)

- Dimensions: 455 x 202 x 440 mm (L x W x H)
- Weight: ~6 kg

2. Package content

- Rebel 9 Pro Economy or Value or Window Edition
- Screw kit:

Screws for mainboard mounting	Screws for PSU mounting	Screws for drive mounting (3.5" and 5.25")	Screws for HDD mounting

- Accessory kit:

Stand-offs for mainboard	Washers	Lock attachment (A) and speaker (B)

	
Mounting angles for HDDs (with decoupling / A) and 3.5" devices (not decoupled / B)	

Quick fasteners for ODDs	5.25" bezel with 3.5" opening

Note:
If you are missing any of the items listed above, please contact our customer service immediately:
support@sharkoon.com (Germany and Europe)
support@sharkoon.com.tw (international).

3. The case at a glance

Front view



A – LED for HDD activity
B – 5.25" drive bays
C – behind the mesh bezel:
pre-installed 120mm fan (Value and Window Edition)

View from above



Front panel:
A – Power and
B – Reset button

Case top:
C – Top I/O with:
a – 1x headphone and microphone connector
b – 2x USB2.0 and
c – 1x eSATA (Economy and Value Edition) / USB3.0 (Window Edition) connector
D – Fan bracket

Side view (closed/left, Economy)

A – Fan brackets (120 mm)

Side view (closed/left)



Value Edition:
A – Pre-installed, adjustable 250mm fan

Window Edition:
A – Acrylic window

Side view (opened/left)



A – Drive bays for 5.25" devices
B – Mainboard mounting panel with:
  a – Installation opening for CPU coolers and
  b – Cable management system

Back side



A – Opening for I/O shield
B – Fan bracket (Economy) or pre-installed 120mm fan (Value and Window Edition)
C – Slot bezels
D – Openings for water cooling
E – PSU bracket
F – Thumb screws

Bottom view



A – Case feet
B – Air intake for PSU

Note:
For more information on how to install the intended devices, refer to their respective documents.

4. Installation of a mainboard

1. Open the case by loosening the thumb screws on the case's back side and removing the left side panel. Lay down the case sidewise on an even surface.
2. The mainboard's mounting panel inside the case provides various drillings to fix the stand-offs (fig. 1).



fig. 1

The mainboard contains special screw openings (fig. 2).

fig. 2

Place the mainboard to the mounting panel. A stand-off must be screwed into every drilling of the mounting panel visible through the mainboard's screw openings.

3. Remove the mainboard and screw the stand-offs into the respective drillings of the mounting panel (fig. 3).

(Stand-offs)

Fig. 3

4. Press the I/O shield (delivered with the mainboard) into the I/O shield opening in the case's back side.

5. Place the mainboard back onto the stand-offs and screw the mainboard to them (fig. 4).

(Screws for mainboard mounting)

fig. 4

6. Plug the connectors of the case's front bezel to the respective connectors of the mainboard (also refer to your mainboard's manual for further information).

   Note (Value and Window edition only):
   The eSATA cable connected to the front eSATA connection should not exceed 50 cm of length otherwise transmission errors may occur! With premium quality eSATA cables this maximum length may be exceeded.

5. Installation of a PSU

1. Set up the case in front of you and put the PSU from the inside against the PSU bracket on the case's back side (fig. 5).

fig. 5

2. Screw the PSU to the case from the outside (fig. 6).

(Screws for PSU mounting)

fig. 6

6. Installation of a HDD

1. Remove the case's right side panel.
2. Attach the decoupled mounting angles to the HDD from both sides (fig. 7).

(Screws for HDD mounting)

(Decoupled mounting angles)

fig. 7

3. Slide the HDD with attached mounting angles into the case's respective drive bay and screw it from both sides (fig. 8).



fig. 8

4. Connect the HDD to the power supply and the mainboard.

7. Installation of an optical device

1. Remove the case's front panel by gently dragging it towards you (fig. 9).

fig. 9

2. Dismantle the 5.25" front bezel from the mounting bay in which you intend to install the drive by loosening its screws and pushing the bezel to the inside (fig. 10). Remove the quick fasteners (fig. 11).

fig. 10

fig. 11

(Carefully take out an optionally present metal bezel covering the 3.5" drive bay by using a gripper.)

3. Slide the optical drive into the case's drive bay (fig. 12).

fig. 12

4. Attach the optical device from both sides using the quick fasteners (fig. 13).

fig. 13

Note:
If you intend to transport the case we recommend securing (additionally) the installed drives:

Screws for 5.25" drive mounting

5. Connect the optical drive to the power supply and the mainboard. (Put the front bezel back onto the case.)

8. Installation of a 3.5" device

(1.Remove the case's front panel by gently dragging it towards you.)
2. Dismantle the 5.25" front bezel from the mounting bay in which you intend to install the drive by loosening its screws and pushing the bezel to the inside (fig. 14). Remove the quick fasteners (fig. 15).

fig. 14

fig. 15

(Carefully take out an optionally present metal bezel covering the drive bay by using a gripper.)

3. Screw the mounting angles to the 3.5" device from both sides (fig. 16).

fig. 16

4. Slide the 3.5" device with attached mounting rails into the case's drive bay (fig. 17) and screw it to the drive bay from both sides (fig. 18).

fig. 17

fig. 18

5. Connect the 3.5" device to the power supply and the mainboard.
6. Screw the 5.25" bezel with 3.5" opening into the front panel (fig. 19) and place it back onto the case.

5.25" bezel with 3.5" opening

fig. 19

9. Installation of an add-on card

1. Remove the slot bezel's fixation screw and take away the slot bezel (fig. 21).

fig. 21

2. Insert the add-on card into the mainboard's respective slot and fix it to the case by re-attaching the fixation screw (fig. 22).



fig. 22

10. The pre-installed fans (Value and Window Edition only)

1. The pre-installed 120mm fans provide a 4-pin PSU connector and a 3-pin mainboard plug each.
2. Connect one of both plugs to either the respective PSU or (to control the fan speed via the mainboard) the matching mainboard connector.

11. Installation of additional fans / optimized airflow

1. Place the fan against the respective bracket from the inside (e.g. in the top panel / fig. 23).

fig. 23

2. Screw the fan to the attachment from the outside (fig. 24).



fig. 24

Note:
The Rebel 9 Pro case offers a lot of possibilities to install fans.
While installing fans make sure that (cool) air is taken in on the case's front side/bottom and blown out on its back side/top. The PC components with the highest heat development should be placed directly within the airflow.

Legal disclaimer:

As a continuing policy of product improvement at SHARKOON, the design and specifications are subject to change without prior notice. National product specifications may vary.

All rights reserved especially (also in extracts) for translation, reprinting, reproduction by copying or other technical means. Infringements will lead to compensation.

All rights reserved especially in case of assignation of patent or utility patent. Means of delivery and technical modifications reserved.

Disposal of your old product
Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2002/96/EC.
Please be informed about the local separate collection system for electrical and electronic products.
Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences to the environment and human health.

© SHARKOON Technologies 2011
www.sharkoon.com